Wireless - N PCI Adapter

Quick Installation Guide

Model # AWN-11N-PCI

Downloaded from www.Manualslib.com manuals search engine

1. Introduction

This is a Wireless PCI Adapter that delivers unrivaled wireless performance for your Desktop PC. It complies with IEEE 802.11n draft standard and backward compatible with IEEE 802.11b/g. This product is made in ISO9001 approved factory and complies with FCC part 15 regulations and CE approval.

1.1 Features

- Complies with draft IEEE 802.11n standard
- Up to 300Mbps data transfer rates in 802.11n mode
- Backward compatible with IEEE 802.11b/g
- Supports 64/128-bit WEP Data Encryption
- Supports WPA, WPA2, WPS, 802.1x advanced security
- Supports both Infrastructure and Ad-Hoc Networking Modes
- Supports Quality of Service (QoS) - WMM, WMM-PS
- Supports Windows 2000/XP/Vista
- Simple user setup and diagnostics utilities

1.2 LED Indicator

LED	Light Status	Description
ACT	Blinking	Data is being transmitted or received.
LINK	On	Wireless link is established.

1.3 Package Contents

- One Wireless PCI Adapter
- Three External Antennas
- One CD-ROM (Drivers / Utility, User's Manual)
- One Quick Installation Guide

If any of the above items is missing, contact your dealer immediately.

2. Installation Procedure

Note: If you have installed the Wireless Adapter driver & utility before, please uninstall the old version first.

2.1 Turn off the computer and insert the Wireless PCI Adapter into the PCI slot of your computer.

2.2 **"Found New Hardware Wizard"** will be displayed after the adapter is installed and the computer is restarted. Please click **Cancel** to continue.

Downloaded from www.Manualslib.com manuals search engine

2.3 Insert the Installation CD into CD-ROM drive then windows below will appear. Click "**Install Driver & Utility"** to begin device driver installation.

2.3.1 **For Windows XP and 2000**

Step1: Please read the following license agreement. Select **I accept the terms of the license agreement** and click **Next** to continue.



Step1.1: In Windows XP, You can choose to configure the adapter through the **Microsoft Zero Configuration Tool** or the **Ralink Configuration Tool**. It is recommended to choose the **Ralink Configuration Tool** for the adapter. Click **Next** to continue.

Downloaded from www.Manualslib.com manuals search engine

Step1.2: If you need better performance, please choose **Optimize for performance mode** to enable **Tx Burst mode**. Or you can choose **Optimize for WiFi mode** to run in standard wireless network.

Step2: Click **Install** to begin the installation.

Step3: After the setup wizard has successfully installed wireless LAN, click **Finish** to exit the wizard.

2.3.2 For Windows Vista

Step1: Please read the following license agreement. Select **I accept the terms of the license agreement** and click **Next** to continue.


Ralink Wireless LAN - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
RALINK Wireless Utility for Windows 98/ME/2000/XP/Vista
Copyright (C) RALINK TECHNOLOGY, CORP. All Rights Reserved.
Thank you for purchasing RALINK Wireless product!
SOFTWARE PRODUCT LICENSE
The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.
1. GRANT OF LICENSE. This End-User License Agreement grants you the following rights:Installation and Use. You may install and use an unlimited number of copies of the SOFTWARE PRODUCT.
Reproduction and Distribution. You may reproduce and distribute an unlimited number of copies of the SOFTWARE PRODUCT; provided that each copy shall be a true and complete copy, including all copyright and trademark notices, and shall be accompanied by a copy of this EULA. Copies of the SOFTWARE PRODUCT may be distributed as a standalone product or included with your own product.
I accept the terms of the license agreement
I do not accept the terms of the license agreement
Print
InstallShield
< Back
Next >
Cancel

Step2: Click **Install** to begin the installation.

Step3: After the setup wizard has successfully installed wireless LAN, click **Finish** to exit the wizard.

2.4 For detailed information of Device Driver & Utility installation, please refer to the user's manual included in the Installation CD.

Downloaded from www.Manualslib.com manuals search engine